

May 31, 2016

[Customer#]
[Name1]
[Name2]
[Contact]
[Address1, Address2]
[City, State, Zip Code]

To: Welch Allyn Distributors & Customers

Re: Atlas Monitor End of Service Life Announcement

From: Christopher Long

Several years ago Welch Allyn discontinued manufacturing and shipment of the Atlas Vital Signs Monitor. Since that time we have continued to provide service and accessories to support continued use of the monitor. Due to the age of the device design we are no longer able to source service components and accessories for the device to adequately maintain service support activities.

This letter is to inform you that effective June 30, 2016, Welch Allyn will discontinue all Technical Phone, Repair / Service, Calibration and Parts Support activities.

We will continue to sell a limited number of accessories, such as Blood Pressure Cuffs, ECG Electrodes, and Nellcor Pulse Oximetry Sensors and Extension Cables.

For all your CO2 accessories please contact our partner Covidien at [1-888-674-3466](tel:1-888-674-3466) or via e-mail at CapnographyOrders@Covidien.com.

We thank you for your business, your partnership, and your loyalty and we look forward to continuing to serve your needs with other Welch Allyn products such as the Connex® Vital Signs Monitor.

If you have any questions regarding the Atlas Monitor End of Service Support (EoSS) announcement or to inquire regarding other Welch Allyn products, please contact Welch Allyn Customer Care, www.welchallyn.com.

Sincerely,

Christopher Long

Product Manager, Vitals Signs Devices

Discontinued Products

P/N	Description	P/N	Description
621NP-J2	ATLAS/BASE MODEL/NEL W/PRINTER	621S0-E2	ATLAS MONTR/BASE MODEL W/O PRT
621NP-J1	ATLAS/BASE MODEL/NEL W/PRINTER	621S0-E1-DEM	ATLAS MONTR/BASE MODEL W/O PRT
621N0-J2	ATLAS/BASE MODEL/NEL-W/O PRNTR	621S0-E1	ATLAS MONTR/BASE MODEL W/O PRT
621N0-J1	ATLAS/BASE MODEL/NEL-W/O PRNTR	621NPN	ATLAS MONITOR/LOW NEL W/PART
621SPN	ATLAS MONITOR/BASE MODEL/PRNTR	621NP-S2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-S2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-S1	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-S1	ATLAS MONITOR-BASE MODEL W/PRT	621NP-P2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-P2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-P1	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-P1	ATLAS MONITOR-BASE MODEL W/PRT	621NP-I2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-J2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-G2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-J1	ATLAS MONITOR-BASE MODEL W/PRT	621NP-F2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-I2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-F1	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-G2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-EC2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-F2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E6	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-F1	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E4	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-EC2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E2	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-E6	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E1T	ATLAS REFURB/BASE MODEL/NEL W/PRINTER
621SP-E4	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E1R	ATLAS REFURB/BASE MODEL/NEL W/PRINTER
621SP-E2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E1C	ATLAS REFURB/BASE MODEL/NEL W/PRINTER
621SP-S2	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E1-EX	ATLAS EXCHANGE/ BASE MODEL/ NEL W/ PRNTR
621SP-S1	ATLAS MONITOR-BASE MODEL W/PRT	621NP-E1	ATLAS/BASE MODEL/NEL W/PRINTER
621SP-P2	ATLAS MONITOR-BASE MODEL W/PRT	621N0N	ATLAS MONITOR/BASE-NEL W/O PRT
621SP-P1	ATLAS MONITOR-BASE MODEL W/PRT	621N0-S2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-J2	ATLAS MONITOR-BASE MODEL W/PRT	621N0-S1	ATLAS MONITOR/BASE/NEL W/O PRT

P/N	Description	P/N	Description
621SP-J1	ATLAS MONITOR-BASE MODEL W/PRT	621N0-P2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-I2	ATLAS MONITOR-BASE MODEL W/PRT	621N0-P1	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-G2	ATLAS MONITOR-BASE MODEL W/PRT	621N0-I2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-F2	ATLAS MONITOR-BASE MODEL W/PRT	621N0-G2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-F1	ATLAS MONITOR-BASE MODEL W/PRT	621N0-F2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-EC2	ATLAS MONITOR-BASE MODEL W/PRT	621N0-F1	ATLAS MONITOR/BASE/NEL W/O PRT
621SP-E6	ATLAS MONITOR-BASE MODEL W/PRT	621N0-EC2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-E4	ATLAS MONITOR-BASE MODEL W/PRT	621N0-E6	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-E2	ATLAS MONITOR-BASE MODEL W/PRT	621N0-E4	ATLAS/BASE MODEL/NEL-W/O PRNTR
621SP-E1SC	ATLAS MONITOR-BASE MODEL W/PRT	621N0-E2	ATLAS/BASE MODEL/NEL-W/O PRNTR
621S0N	ATLAS MONIT BASE MODEL NO PRTR	621N0-E1T	ATLAS REFURB/BASE MODEL/NEL W/O PRNT
621S0-S2	ATLAS MONTR/BASE MODEL W/O PRT	621N0-E1R	ATLAS REFURB/BASE MODEL/NEL W/O PRNT
621S0-S1	ATLAS MONTR/BASE MODEL W/O PRT	621N0-E1C	ATLAS REFURB/BASE MODEL/NEL W/O PRNT
621S0-P2	ATLAS MONTR/BASE MODEL W/O PRT	621N0-E1-EX	ATLAS EXCHANGE/ BASE MODEL/ NEL W/O PRNT
621S0-P1	ATLAS MONTR/BASE MODEL W/O PRT	621N0-E1	ATLAS/BASE MODEL/NEL W/O PRNT
621S0-J2	ATLAS MONTR/BASE MODEL W/O PRT	622NP-J2	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-J1	ATLAS MONTR/BASE MODEL W/O PRT	622NP-J1	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-I2	ATLAS MONTR/BASE MODEL W/O PRT	622NP-E6-DEM	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-G2	ATLAS MONTR/BASE MODEL W/O PRT	622NP-E4-DEM	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-F2	ATLAS MONTR/BASE MODEL W/O PRT	622NP-E2-DEM	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-F1	ATLAS MONTR/BASE MODEL W/O PRT	622NP-E1SC	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-EC2	ATLAS MONTR/BASE MODEL W/O PRT	622NP-E1-DEM	ATLAS MONITOR/MID/NEL W/PRNTR
621S0-E6	ATLAS MONTR/BASE MODEL W/O PRT	622N0-J2	ATLAS MONITOR/MID/NEL W/O PRNT
621S0-E4	ATLAS MONTR/BASE MODEL W/O PRT	621N0-E1C	ATLAS REFURB/BASE MODEL/NEL W/O PRNT
621N0-E1-EX	ATLAS EXCHANGE/ BASE MODEL/ NEL W/O PRNT	622S0-E6	ATLAS MONITOR/MID/NON-W/O PRNT

P/N	Description	P/N	Description
621N0-E1	ATLAS/BASE MODEL/NEL W/O PRNT	622S0-E4	ATLAS MONITOR/MID/NON-W/O PRNT
622NP-J2	ATLAS MONITOR/MID/NEL W/PRNTR	622S0-E2	ATLAS MONITOR/MID/NON-W/O PRNT
622NP-J1	ATLAS MONITOR/MID/NEL W/PRNTR	622S0-E1-DEM	ATLAS MONITOR/MID/NON-W/O PRNT
622NP-E6-DEM	ATLAS MONITOR/MID/NEL W/PRNTR	622S0-E1	ATLAS MONITOR/MID/NON-W/O PRNT
622NP-E4-DEM	ATLAS MONITOR/MID/NEL W/PRNTR	622NPN	ATLAS MONITOR/MID/NEL/PRINTER
622NP-E2-DEM	ATLAS MONITOR/MID/NEL W/PRNTR	622NP-S2	ATLAS MONITOR/MID/NEL W/PRNTR
622NP-E1SC	ATLAS MONITOR/MID/NEL W/PRNTR	622NP-S1	ATLAS MONITOR/MID/NEL W/PRNTR
622NP-E1-DEM	ATLAS MONITOR/MID/NEL W/PRNTR	622NP-P2	ATLAS MONITOR/MID/NEL W/PRNTR
622N0-J2	ATLAS MONITOR/MID/NEL W/O PRNT	622NP-P1	ATLAS MONITOR/MID/NEL W/PRNTR
622N0-J1	ATLAS MONITOR/MID/NEL W/O PRNT	622NP-I2	ATLAS MONITOR/MID/NEL W/PRNTR
622N0-E1-DEM	ATLAS MONITOR/MID/NEL W/O PRNT	622NP-G2	ATLAS MONITOR/MID/NEL W/PRNTR
622SPN	ATLAS MONITOR/MID/NON/PRINTER	622NP-F2	ATLAS MONITOR/MID/NEL W/PRNTR
622SP-S2	ATLAS MONITOR/MID/NON- W/PRNT	622NP-F1	ATLAS MONITOR/MID/NEL W/PRNTR
622SP-S1	ATLAS MONITOR/MID/NON- W/PRNT	622NP-EC2	ATLAS MONITOR/MID/NEL W/PRNT
622SP-P2	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E6	ATLAS MONITOR/MID/NEL W/PRNTR
622SP-P1	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E4	ATLAS MONITOR/MID/NEL W/PRNTR
622SP-J2	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E2	ATLAS MONITOR/MID/NEL W/PRNT
622SP-J1	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E1T	ATLAS REFURB/MID/NEL-W/PRINTER
622SP-I2	ATLAS MONIOTR/MID/NON- W/PRNT	622NP-E1R	ATLAS REFURB/MID/NEL-W/PRINTER
622SP-G2	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E1C	ATLAS REFURB/MID/NEL-W/PRINTER
622SP-F2	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E1-EX	ATLAS MONITOR EXCHANGE/ MID/ NEL W/ PRNTR
622SP-F1	ATLAS MONITOR/MID/NON- W/PRNT	622NP-E1	ATLAS MONITOR/MID/NEL W/PRNTR
622SP-EC2	ATLAS MONITOR/MID/NON- W/PRNT	622N0N	ATLAS MONITOR/MID/NEL-W/O PRNT
622SP-E6	ATLAS MONITOR/MID/NON- W/PRNT	622N0-S2	ATLAS MONITOR/MID/NEL W/O PRNT
622SP-E4	ATLAS MONITOR/MID/NON- W/PRNT	622N0-S1	ATLAS MONITOR/MID/NEL W/O PRNT
622SP-E2-DEM	ATLAS MONITOR/MID/NON- W/PRNT	622N0-P2	ATLAS MONITOR/MID/NEL W/O PRNT

P/N	Description	P/N	Description
622SP-E2	ATLAS MONITOR/MID/NON- W/PRNT	622N0-P1	ATLAS MONITOR/MID/NEL W/O PRNT
622SP-E1SC	ATLAS MONITOR/MID/NON- W/PRNT	622N0-I2	ATLAS MONITOR/MID/NEL W/O PRNT
622SP-E1-DEM	ATLAS MONITOR/MID/NON- W/PRNT	622N0-G2	ATLAS MONITOR/MID/NEL W/O PRNT
622SP-E1	ATLAS MONITOR/MID/NON- W/PRNT	622N0-F2	ATLAS MONITOR/MID/NEL W/O PRNT
622S0N	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-F1	ATLAS MONITOR/MID/NEL W/O PRNT
622S0-S2	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-EC2	ATLAS MONITOR-MID/NEL W/O PRNT
622S0-S1	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E6	ATLAS MONITOR/MID/NEL W/O PRNT
622S0-P2	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E4	ATLAS MONITOR/MID/NEL W/O PRNT
622S0-P1	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E2	ATLAS MONITOR-MID/NEL W/O PRNT
622S0-J2	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E1T	ATLAS REFURB/BASE MODEL/NEL W/O PRINTER
622S0-J1	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E1R	ATLAS REFURB/BASE MODEL/NEL W/O PRINTER
622S0-I2	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E1C	ATLAS REFURB/BASE MODEL/NEL W/O PRINTER
622S0-G2	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E1-EX	ATLAS MONITOR/ MID/ NEL W/ O PRNT/ EXCHANGE
622S0-F2	ATLAS MONITOR/MID/NON-W/O PRNT	622N0-E1	ATLAS MONITOR/MID/NEL W/O PRNT
622S0-F1	ATLAS MONITOR/MID/NON-W/O PRNT	623NP-J2	ATLAS MONITOR/HGH/NEL-W/PRNT
622S0-EC2	ATLAS MONITOR/MID/NON-W/O PRNT	623NP-J1	ATLAS MONITOR/HIGH/NEL-W/PRNT
623NP-E6-DEM	ATLAS MONITOR/HIGH/NEL-W/PRNT	623SP-E1SC	ATLAS MONITOR/HIGH/NON-W/PRNTR
623NP-E4-DEM	ATLAS MONITOR/HIGH/NEL-W/PRNTR	623SP-E1-DEM	ATLAS MONITOR/HIGH/NON-W/PRNTR
623NP-E2-DEM	ATLAS MONITOR/HIGH/NEL W-PRNT	623SP-E1	ATLAS MONITOR/HIGH/NON-W/PRNTR
623NP-E1SC	ATLAS MONITOR/HIGH/NEL-W/PRNT	623NPN	ATLAS MONITOR/HIGH/NEL/PRNTR
623NP-E1-DEM	ATLAS MONITOR/HIGH/NEL W/PRNT	623NP-S2	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SPN	ATLAS MONITOR/HIGH/NON/PRNTR	623NP-S1	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-S2	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-P2	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-S1	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-P1	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-P2	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-I2	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-P1	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-G2	ATLAS MONITOR/HGH/NEL-W/PRNT

P/N	Description	P/N	Description
623SP-J2	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-F2	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-J1	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-F1	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-I2	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-EC2	ATLAS MONITOR/HIGH/NEL W/PRNT
623SP-G2	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-E6	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-F2	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-E4	ATLAS MONITOR/HIGH/NEL-W/PRNT
623SP-F1	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-E2	ATLAS MONITOR/HIGH/NEL W/PRNT
623SP-EC2	ATAS MONITOR/HIGH/NON W/PRNTER	623NP-E1T	ATLAS REFURB/HIGH/NEL-W/PRINTER
623SP-E6-DEM	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-E1R	ATLAS REFURB/HIGH/NEL-W/PRINTER
623SP-E6	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-E1C	ATLAS REFURB/HIGH/NEL- W/PRINTER
623SP-E4-DEM	ATLAS MONITOR/HIGH/NON-W/PRNTR	623NP-E1-EX	ATLAS MONITOR EXCHANGE/ HIGH/ NEL - W/ PRNT
623SP-E4	ATLAS MONITOR/HIGH/NON-W/PRNTR	623SP-E2	ATLAS MONITOR/HIGH/NON W/PRNTR